

***ANEXO XII***

***AGRUPAMENTO DAS TAREFAS: 4000 FH E C1 (5000 FH)***

<b>Amtoss</b>	<b>Description</b>		<b>Threshold</b>	<b>MPD Int.</b>	<b>PGA Int.</b>	<b>Origin</b>
<b>062701-00-01</b>	<b>MLG BAY</b> SURV. INSP. OF MLG AND MLG DOORS	IN		4000 FH	4000 FH	MPD
DRF_4000	<b>NOTE:</b> MLG DOORS TO BE OPENED.					
<b>212300-00-03</b>	<b>AIR CONDITIONING</b> DISCARD RECIRCULATION AIR FILTERS	DS		4000 FH	4000 FH	MPD
DRF_4000						
<b>221100-00-04</b>	<b>AUTOPILOT</b> LUBRICATION OF (AUTOPILOT) AILERON, ELEVATOR & RUDDER RVDT HOUSING ASSYS	LU		4000 FH	4000 FH	MPD
DRF_4000	<b>NOTE:</b> MLG DOORS TO BE OPENED.					
<b>222100-00-03</b>	<b>AUTOPILOT</b> LUBRICATION OF (AUTOPILOT) YAW DAMPER ACTUATORS HINGE POINTS	LU		4000 FH	4000 FH	MPD
DRF_4000						
<b>222100-00-08</b>	<b>AUTOPILOT</b> LUBRICATION OF (AUTOPILOT) STAB. RVDT HOUSING ASSY	LU		4000 FH	4000 FH	MPD
DRF_4000						
<b>271100-00-02</b>	<b>AILERON QUADRANT</b> LUBRICATION OF SHAFT ASSEMBLY OF AILERON QUADRANTE IN TUNNEL BETWEEN WHEEL BAYS	LU		4000 FH	4000 FH	MPD
DRF_4000	<b>NOTE:</b> MLG DOORS TO BE OPENED.					
<b>271100-00-03</b>	<b>CABLE TENSION REG.</b> LUBRICATION AILERON CABLE TENSION REGULATOR CROSS HEAD WIPERS	LU		4000 FH	4000 FH	MPD
DRF_4000	<b>NOTE:</b> MLG DOORS TO BE OPENED.					
<b>271100-00-04</b>	<b>AILERON QUADRANT</b> LUBRICATION OF AILERON INPUT QUADRANT ASSY & THE ANTI UPFLOAT QUADRANT ASSY	LU		4000 FH	4000 FH	MPD
DRF_4000						
<b>271100-00-05</b>	<b>AIL. OVERRIDE UNITS</b> LUBRICATION OF SUPPORT BRACKETS & INPUT LEVEL OF THE AILERON OVERRIDE UNITS	LU		4000 FH	4000 FH	MPD
DRF_4000	<b>NOTE:</b> MLG DOORS TO BE OPENED.					
<b>271100-00-07</b>	<b>AILERON</b> LUBRICATION OF AILERON HINGE BEARINGS, AILERON TAB HINGE BEARINGS & SPIGOT BEARINGS	LU		4000 FH	4000 FH	MPD
DRF_4000						
<b>271100-00-09</b>	<b>AILERON SYSTEM</b> OIL LEVEL CHECK OF AILERON FLUTTER DAMPER RECUPERATOR	IN		4000 FH	4000 FH	MPD
DRF_4000	<b>NOTE:</b> AILERONS TO BE EXTEND UPWARDS.					
<b>271300-00-01</b>	<b>AIL. ELECTRICAL CTL.</b> OPERATIONAL CHECK OF AILERON SERVO VALVE STICKING SWITCHES	OP		4000 FH	4000 FH	MPD
CMR 2 <sup>a</sup>						
DRF_4000	<b>NOTE:</b> THIS TASK IS IN "SYSTEMS AND POWERPLANT -SEC.2" OF MRB, WITH INT.:4000F AND, AT THE SAME TIME, IN "APPENDICES-SEC,5" OF MRB WITH INT.4500FH (CMR**-271300-CM-06)					

<b>Amtoss</b>	<b>Description</b>		<b>Threshold</b>	<b>MPD Int.</b>	<b>PGA Int.</b>	<b>Origin</b>
271400-00-01	<b>AIL. TRIM CONTROL</b>	LU		4000 FH	4000 FH	MPD
	LUBRICATION OF AILERON TRIM SCREW ACTUATOR, DRIVE CHAIN, CHAIN TENSIONER & LINK ROD					
DRF_4000	<b>NOTE:</b> MLG DOORS TO BE OPENED.					
272100-00-01	<b>RUDDER SYSTEM</b>	LU		4000 FH	4000 FH	MPD
	LUBRICATION OF RUDDER POST ASSY & RUDDER PILAR ASSY					
DRF_4000						
272100-00-02	<b>RUDDER SYSTEM</b>	LU		4000 FH	4000 FH	MPD
	LUBRICATION OF RUDDER HINGE BEARINGS & RUDDER SPIGOT BEARING					
DRF_4000	<b>NOTE:</b> SPEED BRAKE OPENED AND SECURED WITH GROUND LOCK.					
272100-00-03	<b>RUDDER SYSTEM</b>	IN		4000 FH	4000 FH	MPD
	OIL LEVEL CHECK OF RUDDER FLUTTER DAMPERS RECUPERATOR					
DRF_4000						
272200-00-01	<b>RUDDER SYSTEM</b>	LU		4000 FH	4000 FH	MPD
	LUBRICATION OF RUDDER ACTUATOR EYE-END BEARINGS					
DRF_4000						
272300-00-01	<b>RUD.ELECTRICAL CTL.</b>	OP		4000 FH	4000 FH	MPD
CMR 2 <sup>a</sup>	OPERATIONAL CHECK OF RUDDER SERVO MOUNTS STICKING SWITCH					
DRF_4000	<b>NOTE:</b> THIS TASK IS IN "SYSTEMS AND POWERPLANT -SEC.2" OF MRB, WITH INT.:4000F AND, AT THE SAME TIME, IN "APPENDICES-SEC,5" OF MRB WITH INT.4500FH (CMR**-271300-CM-06)					
272300-00-03	<b>RUD.ELECTRICAL CTL.</b>	OP		4000 FH	4000 FH	MPD
	OP. CHECK OF RUDDER LIMITER/MONITOR					
DRF_4000						
272400-00-01	<b>RUDDER TRIM CTL.</b>	LU		4000 FH	4000 FH	MPD
	LUBRICATION OF RUDDER TRIM SCREW ACTUATOR & DRIVE RODS					
DRF_4000						
273100-00-01	<b>ELEVATOR SYS.</b>	LU		4000 FH	4000 FH	MPD
	LUBRICATION OF ELEVATOR CABLE TENSION REGULATOR					
DRF_4000						
273100-00-03	<b>ELEVATOR SYS.</b>	LU		4000 FH	4000 FH	MPD
	LUBRICATION OF ELEVATOR PUSH-PULL RODS					
DRF_4000						
273100-00-05	<b>ELEVATOR SYS.</b>	LU		4000 FH	4000 FH	MPD
	LUBRICATION OF ELEVATOR HINGE BEARINGS					
DRF_4000						

<b>Amtoss</b>	<b>Description</b>	<b>Threshold</b>	<b>MPD Int.</b>	<b>PGA Int.</b>	<b>Origin</b>
273300-00-01 CMR 2 <sup>a</sup>  DRF_4000	<b>ELEV.ELECTRICAL CTL.</b> OP OP. CHECK OF ELEVATOR SERVO VALVE STICKING SWITCH  <b>NOTE:</b> THIS TASK IS IN "SYSTEMS AND POWERPLANT -SEC.2" OF MRB, WITH INT.:4000F AND, AT THE SAME TIME, IN "APPENDICES-SEC,5" OF MRB WITH INT.4500FH (CMR**-271300-CM-06)		4000 FH	4000 FH	MPD
275001-00-02  DRF_4000	<b>FLAP SYSTEM</b> LU LUBRICATION OF SHROUD DOOR HINGES, SPRING BOX ASSYS & OF MOVEABLE FAIRING DOORS FLAP TRACK RAILS  <b>NOTE:</b> FLAPS TO BE EXTENDED.		4000 FH	4000 FH	MPD
275200-00-01  DRF_4000	<b>FLAP HYDRAULIC CTL.</b> SV DRAIN FLAP MOTOR SEAL DRAIN TANK  <b>NOTE:</b> LH MLG DOOR TO BE OPENED.		4000 FH	4000 FH	MPD
275300-00-03  DRF_4000	<b>FLAP MECHANICAL DRIVE</b> IN LUBRICATION OF DRIVE SHAFT SUPPORT BEARINGS  <b>NOTE:</b> MLG DOORS TO BE OPENED.		4000 FH	4000 FH	MPD
275300-00-09  DRF_4000	<b>FLAP MECHANICAL DRIVE</b> IN SURV. INSP. OF DRIVE SHAFT (INCL. FLEXIBLE), FLAP ACTUATORS, FLAP CARIADGES, A-FRAME ROLLERS		4000 FH	4000 FH	MPD
276400-00-08  DRF_4000	<b>LIFTDUMPERS HYD. CTL.</b> IN DETAILED INSPECTION OF LIFTDUMPER MECHANICAL DRIVE SYSTEM AND HYDRAULIC ACTUATORS.		4000 FH	4000 FH	MPD
277100-00-02  DRF_4000	<b>FLIGHT CONTROL LOCK</b> LU LUBRICATION OF AILERON ANTI-UPFLOAT CABLE CONTROL LOCK  <b>NOTE:</b> MLG DOORS TO BE OPENED.		4000 FH	4000 FH	MPD
277100-00-03  DRF_4000	<b>FLIGHT CONTROL LOCK</b> LU LUB. OF ELEVATOR CONTROL LOCK		4000 FH	4000 FH	MPD
282300-00-01  DRF_4000	<b>FUEL CROSSFEED SYS</b> OP OP. CHECK OF CROSSFEED SYSTEM		4000 FH	4000 FH	MPD
313100-01-04  DRF_4000	<b>FLIGHT DATA RECORDER</b> IN CHECK READ-OUT OF ALL MANDATORY PARAMETERS  <b>NOTE:</b> REF. TO NATIONAL REQUIREMENTS FOR THE MANDATORY PARAMETERS		4000 FH	4000 FH	MPD
322100-00-09  DRF_4000	<b>NOSE LANDING GEAR</b> IN INSPECTION OF SHIMMY DAMPER END FLOAT  <b>NOTE:</b> DO THE BEDDING DOWN ADJUSTMENT ON A NEW OR OVERHAULED NLG BETWEEN 500 AND 1000 FC <b>NOTE:</b> PER.SMRD INTV 4000FH.		4000 FH	4000 FH	MPD
323200-00-01  DRF_4000	<b>LG. HYD. CONTROL</b> LU LUB. OF EXTENSION AND RETRACTION HYDRAULIC CONTROL COMPONENTS  <b>NOTE:</b> RH MLG DOOR OPEN.		4000 FH	4000 FH	MPD

<b>Amtoss</b>	<b>Description</b>		<b>Threshold</b>	<b>MPD Int.</b>	<b>PGA Int.</b>	<b>Origin</b>
323300-00-02 CMR 2 <sup>a</sup>  DRF_4000	<b>LANDING GEAR</b> FUNCTIONAL CHECK OF LANDING GEAR ALTERNATE CONTROL	FC		4000 FH	4000 FH	MPD
325100-00-01  DRF-4000	<b>NLG STEERING MECH.</b> LUBRICATION OF NOSE WHEEL STEERING CONTROL UNIT	LU		4000 FH	4000 FH	MPD
711000-00-01  DRF_4000	<b>COWLING</b> SURV. INSP. OF COWLING AND FIRE SEALS  <b>NOTE:</b> THRUST REVERSER DOORS OPEN.	IN		4000 FH	4000 FH	MPD
774600-00-01 CMR 2 <sup>a</sup>	<b>ENGINE VIB. INDICATING</b> FUNCTIONAL CHECK OF ENGINE VIBRATION MONITOR (EVM)	FC		4000 FH	4000 FH	MPD

---

<i>Amtoss</i>	<i>Description</i>	<i>Threshold</i>	<i>MPD Int.</i>	<i>PGA Int.</i>	<i>Origin</i>
	Quantity of tasks in this category				39

---

<b>Amtoss</b>	<b>Description</b>	<b>Threshold</b>	<b>MPD Int.</b>	<b>PGA Int.</b>	<b>Origin</b>
062304-00-01 DRF_4000	<b>APU ENCLOSURE</b> IN SURV. INSP. OF APU ENCLOSURE, INTERNALLY		3600 FH	4000 FH	MPD
236000-00-03 DRF_4000	<b>ELECTRICAL BONDING</b> IN SURV. INSP. OF BONDING WIRES OF RADOME, HOR. STAB., VERT. STAB., ELEVATORS, FLAP AND AILERON.		3000 FH	4000 FH	MPD
243000-00-01 DRF_4000	<b>DC GENERATION</b> OP OPERATIONAL CHECK OF DC ESSENTIAL & DC EMERGENCY BUS		3600 FH	4000 FH	MPD
274300-00-01 CMR 1 <sup>a</sup> DRF_4000	<b>HOR. STABILIZER SYS</b> OP OP. CHECK OF STAB. SERVO VALVE STICKING SWITCH		4500 FH	4000 FH	MPD
302000-00-04 DRF_4000	<b>ENGINE AIR INTAKE</b> FC FUNCTIONAL CHECK OF PRESSURE REGULATING AND SHUTOFF VALVES		3000 FH	4000 FH	MPD

---

<i>Amtoss</i>	<i>Description</i>	<i>Threshold</i>	<i>MPD Int.</i>	<i>PGA Int.</i>	<i>Origin</i>
	Quantity of tasks in this category				5

---

<b>Amtoss</b>	<b>Description</b>	<b>Threshold</b>	<b>MPD Int.</b>	<b>PGA Int.</b>	<b>Origin</b>
062102-00-01	<b>LOWER PART OF FUSELAGE</b> IN SURVEILLANCE INSPECTION OF LOWER PART OF FUSELAGE, EXTERNALLY  <b>NOTE:</b> CHECK FUSELAGE-TO-WING AERODYN. FAIRINGS.	5000 FH	1 C	MPD	
062104-00-01	<b>NLG BAY</b> IN SURVEILLANCE INSPECTION OF NOSE LANDING GEAR BAY AND DOORS  <b>NOTE:</b> APPLY CIC. <b>NOTE:</b> CHECK THE INTEGRITY OF THE HOSES AND THE CORRECT ATTACHMENT <b>NOTE:</b> NLG DOORS OPEN.	5000 FH	1 C	MPD	
062107-00-01	<b>UNDER COCKPIT FLOOR</b> IN SURVEILLANCE INSPECTION OF EQUIPMENT COOLING COMPARTMENTS, INTERNALLY	5000 FH	1 C	MPD	
062111-00-01	<b>KEEL / CENTER SECTION</b> IN SURVEILLANCE INSPECTION OF MLG WHEEL BAYS, LANDING GEAR DOORS AND HYDRAULIC TUNNEL, INTERNALLY.  <b>NOTE:</b> APPLY CIC. <b>NOTE:</b> MLG DOORS TO BE OPENED. <b>NOTE:</b> PAY SPECIAL ATTENTION TO THE CLEARANCE BETWEEN THE FUEL AND THE HYDRAULIC LINES	5000 FH	1 C	MPD	
062201-00-01	<b>AREAS ABOVE FLOOR</b> IN SURV. INSP. OF UPPER PART OF FUSELAGE, EXTERNALLY  <b>NOTE:</b> CHECK CABIN AND FLIGHT COMPT. WINDOWS FOR TRANSPARENCY CONDITION, SCRATCHES AND CRAZING	5000 FH	1 C	MPD	
062301-00-01	<b>REAR FUSELAGE</b> IN SURVEILLANCE INSPECTION OF REAR FUSELAGE, EXTERNALLY	5000 FH	1 C	MPD	
062305-00-01	<b>APU COMPARTMENT</b> IN SURV. INSP. OF AREAS AFT OF REAR PRESSURE BULKHEAD EXCLUDING AREA BELOW APU ENCLOSURE, INTERNAL.  <b>NOTE:</b> APPLY CIC.	5000 FH	1 C	MPD	
062307-00-01	<b>VERT STABILIZER</b> IN SURV. INSP. STAB OF VERTICAL STABILIZER, INTERNALLY (VERTICAL STAB. TIP EXCLUDED)  <b>NOTE:</b> APPLY CIC. <b>NOTE:</b> OPEN SPEEDBRAKES.	5000 FH	1 C	MPD	
062308-00-01	<b>VERT STABILIZER</b> IN SURV. INSP. OF VERT. STABILIZER TIP AND BULLET FAIRING AREA , INTERNALLY  <b>NOTE:</b> APPLY CIC (S) AT FUSELAGE TAIL SECTION ZONE 340	5000 FH	1 C	MPD	
062401-00-02	<b>STUBWING, INT.</b> IN SURV. INSP. OF STUBWING, INTERNALLY.	5000 FH	1 C	MPD	

<b>Amtoss</b>	<b>Description</b>		<b>Threshold</b>	<b>MPD Int.</b>	<b>PGA Int.</b>	<b>Origin</b>
062404-00-02	<b>NACELLE, INT.</b> SURV. INSP. OF THRUST REVERSER SECTION , INTERNALLY  <b>NOTE:</b> OPEN THRUST REVERSER DOORS.	IN		5000 FH	1 C	MPD
062502-00-01	<b>LEFT WING</b> SURV. INSP OF LEFT WING LOWER PART, FLAPS AND LEADING EDGES, EXTERNALLY  <b>NOTE:</b> EXTEND FLAPS, DEFLECT AILERON AND AILERON TAB.	IN		5000 FH	1 C	MPD
062505-00-01	<b>LEFT WING</b> SURV. INSP. OF LEFT WING TRAILING EDGE, INTERNALLY  <b>NOTE:</b> APPLY CIC ON REAR SPAR AFT SIDE. - CHECK AILERON HINGE FITTINGS AND SPIGOTS <b>NOTE:</b> EXTEND FLAPS, LIFTDUMPERS UP.	IN		5000 FH	1 C	MPD
062507-00-01	<b>LEFT WING</b> SURVEILLANCE OF LEFT WING AILERON, INTERNALLY  <b>NOTE:</b> DEFLECT AILERON AND AILERON TAB.	IN		5000 FH	1 C	MPD
062508-00-01	<b>LEFT WING</b> SURV. INSP. OF LH MLG WHEEL BAY AND STRUT BAY, INTERNALLY  <b>NOTE:</b> MLG DOORS TO BE OPENED.	IN		5000 FH	1 C	MPD
062602-00-01	<b>RIGHT WING</b> SURV. INSP. OF RIGHT WING LOWER PART, FLAPS AND LEADING EDGES, EXTERNALLY  <b>NOTE:</b> EXTEND FLAPS, DEFLECT AILERON AND AILERON TAB.	IN		5000 FH	1 C	MPD
062605-00-01	<b>RIGHT WING</b> SURV. INSP. OF RIGHT WING TRAILING EDGE, INTERNALLY  <b>NOTE:</b> APPLY CIC ON REAR SPAR AFT SIDE. - CHECK AILERON HINGE FITTINGS AND SPIGOTS <b>NOTE:</b> EXTEND FLAPS, LIFTDUMPERS UP.	IN		5000 FH	1 C	MPD
062607-00-01	<b>RIGHT WING</b> SURV. INSP. OF RIGHT WING AILERON, INTERNALLY  <b>NOTE:</b> DEFLECT AILERON TAB.	IN		5000 FH	1 C	MPD
062608-00-01	<b>RIGHT WING</b> SURV. INSP. OF RH MLG STRUT BAY AND WHELL BAY, INTERNALLY  <b>NOTE:</b> MLG DOORS TO BE OPENED.	IN		5000 FH	1 C	MPD
062702-00-01	<b>NLG BAY</b> SURV. INSP. OF NLG AND NLG DOORS	IN		5000 FH	1 C	MPD

<b>Amtoss</b>	<b>Description</b>	<b>Threshold</b>	<b>MPD Int.</b>	<b>PGA Int.</b>	<b>Origin</b>
062801-00-01	<b>DOORS</b> IN SURV. INSP. OF PAX DOOR, EMERGENCY EXITS, SERVICE/EMERGENCY DOORS AND CARGO DOORS, EXTERNALLY  <b>NOTE:</b> CHECK ALSO DOOR SEALS, APERTURE STRUCTURE AND PARKING DOOR HOOKS AS APLICABLE.  <b>NOTE:</b> OPEN DOORS INCLUDING OVERWING EMERG. EXITS.		5000 FH	1 C	MPD
212300-00-01	<b>AIR CONDITIONING</b> OP OPERATIONAL CHECK OF RECIRCULATION FANS		5000 FH	1 C	MPD
212600-00-03	<b>EQUIPMENT COOLING</b> OP OPERATIONAL CHECK OF EFIS EMERGENCY COOLING FAN		5000 FH	1 C	MPD
212600-00-04	<b>EQUIPMENT COOLING</b> OP OPERATIONAL CHECK OF BLOW & SUCTION FLOW SENSORS		5000 FH	1 C	MPD
212630-01-02	<b>EQUIPMENT COOLING</b> OP OPERATIONAL CHECK OF THIRD AVIONICS COOLING FAN LOW SPEED DETECTION SYSTEM		5000 FH	1 C	MPD
213000-00-01	<b>AIR CONDITIONING</b> RS CLEAN PRIMARY & SECONDARY OUTFLOW VALVES  HT213000 <b>NOTE:</b> OPTIONAL MAINTENANCE TASK: 213100-50- 02 <b>NOTE:</b> PMI TASK FOR PRIMARY OUTFLOW VALVE HT213000, FOR SECONDARY, HT213001. <b>NOTE:</b> THIS TASK IMPLIES REMOVAL OF BOTH OUTFLOW VALVES FOR BENCH CHECK		5000 FH	1 C	MPD
213000-00-07	<b>PRESSURIZATION CTRL.</b> OP OPERATIONAL CHECK OF CABIN ALTITUDE WARNING		5000 FH	1 C	MPD
221100-00-02	<b>AUTOPILOT</b> IN INSP. OF (AUTOPILOT) AILERON, ELEVATOR & RUDDER SERVO MOUNTS FOR LOOSE RODS, LOOSE LEVERS & LOOSE MOUNTS  <b>NOTE:</b> REM.PEDESTAL COVERS AND CTRL.COLUMN-WHEEL COVERS.		5000 FH	1 C	MPD
222100-00-01	<b>AUTOPILOT</b> IN INSP. OF (AUTOPILOT) OF STAB.-TRIM SERVO MOUNTS FOR LOOSE MOUNTS		5000 FH	1 C	MPD
243000-00-02	<b>DC BUS TRANSFER</b> OP OPERATIONAL CHECK OF DC BUS TRANSFER		5000 FH	1 C	MPD
251101-00-04	<b>CAPT AND F/O SEAT</b> IN SURV. INSP. OF CAPTAIN AND 1ST OFFICER SEATS LAPBELT AND SHOULDER HARNESS		5000 FH	1 C	MPD

<b>Amtoss</b>	<b>Description</b>		<b>Threshold</b>	<b>MPD Int.</b>	<b>PGA Int.</b>	<b>Origin</b>
251104-00-02	<b>OBSERVER SEAT</b> SURV. INSP. OF OBSERVER SEAT HARNESS	IN		5000 FH	1 C	MPD
251104-00-03	<b>OBSERVER SEAT</b> OP. CHECK OF OBSERVER SEAT ROTARY BUCKLE	OP		5000 FH	1 C	MPD
252101-00-03	<b>PASSENGER SEATS</b> SURV. INSP. OF PASSENGER SEAT BELTS <b>NOTE:</b> FUNC. CHECK ALSO RECLINE MECHANISM.	IN		5000 FH	1 C	MPD
252103-00-02	<b>ATTENDANT SEAT</b> SURV. INSP. OF FLIGHT ATTENDANT SEATS HARNESS	IN		5000 FH	1 C	MPD
252103-00-03	<b>ATTENDANT SEAT</b> OPERATIONAL CHECK OF FLIGHT ATTENDANT SEATS INERTIA REEL <b>NOTE:</b> ALSO OPERATIONAL CHECK OF SEAT.	OP		5000 FH	1 C	MPD
253110-00-01	<b>GALLEYS</b> DETAILED INSP. OF GALLEY EQUIPMENT RESTRAINTS <b>NOTE:</b> OPC SWIVEL LOCKS, DOOR LOCKS, CONTROL SWITCH PANELS AND HOTCUP CONNECTION FOR ALL GALLEYS AS APLICABLE.	IN		5000 FH	1 C	MPD
261100-00-02	<b>ENGINE FIRE DETECTION</b> OPERATIONAL CHECK OF ENGINE LOOP FAULT WARNING SYSTEM	OP		5000 FH	1 C	MPD
261200-00-02	<b>APU FIRE DETECTION</b> OP. CHECK OF APU LOOP FAULT WARNING SYSTEM	OP		5000 FH	1 C	MPD
262200-00-04	<b>APU FIRE EXTING.</b> OP. CHECK OF APU FIRE EXTINGUISHING SYSTEM	OP		5000 FH	1 C	MPD
270001-00-02	<b>FLIGHT CTL. CABLES</b> DETAILED INSP. OF FLIGHT CONTROL CABLES IN MLG WHEEL BAY AND STRUT BAY, TRAILING EDGE AND IN TUNNEL BETWEEN THE WHEEL BAYS <b>NOTE:</b> MLG DOORS TO BE OPENED.	IN		5000 FH	1 C	MPD
270001-00-05	<b>FLIGHT CTL. CABLES</b> SURV. INSP. OF PULLEYS, FAIR LEADS, PRESSURE SEALS AND BRACKETS OF FLIGHT CONTROL CABLE SYSTEM IN MLG WHEEL AND STRUT BAY, WING TRAILING EDGE AND IN TUNNEL BETWEEN THE WHEEL BAYS. <b>NOTE:</b> MLG DOORS TO BE OPENED.	IN		5000 FH	1 C	MPD
270001-00-07	<b>FLIGHT CTL. CABLES</b> DETAILED INSPECTION OF AILERON CABLE PULLEYS AT WS 1700	IN		5000 FH	1 C	MPD

<b>Amtoss</b>	<b>Description</b>		<b>Threshold</b>	<b>MPD Int.</b>	<b>PGA Int.</b>	<b>Origin</b>
270100-00-01	<b>TAKE OFF WARNING</b> OP. CHECK OF TAKE OFF WARNING SYSTEM	OP	5000 FH	1 C	MPD	
271100-00-08	<b>AILERON MECH. CTL.</b> OP. CHECK OF AILERONS TAB DRIVE SYSTEM & ANTI-UPFLOAT SYSTEM	OP	5000 FH	1 C	MPD	
271100-00-14	<b>AIL. OVERRIDE UNITS</b> SURV. INSP. OF AILERON OVERRIDE UNITS <b>NOTE:</b> MLG DOORS TO BE OPENED.	IN	5000 FH	1 C	MPD	
271100-00-18	<b>AILERON FLUTTER DAMPER</b> SURV. INSP. OF AILERON FLUTTER DAMPERS & OPERATING MECHANISM	IN	5000 FH	1 C	MPD	
271100-00-19	<b>AILERON SYSTEM</b> FUNCTIONAL CHECK OF AILERON CABLE TENSION REGULATOR <b>NOTE:</b> MLG DOORS TO BE OPENED.	FC	5000 FH	1 C	MPD	
271100-00-20	<b>AILERON SYSTEM</b> INSPECTION OF THE CLEARANCE BETWEEN THE HYDRAULIC LINES OF THE ACTUATOR AND THE TAB DRIVE ROD.	IN	5000 FH	1 C	MPD	
272100-00-09	<b>RUDDER FLUTTER DAMPER.</b> SURV. INSP. OF RUDDER FLUTTER DAMPERS & OPERATING MECHANISM	IN	5000 FH	1 C	MPD	
272300-00-04	<b>RUD.ELECTRICAL CTL.</b> OP. CHECK OF RUDDER CTRL. CHANGE-OVER SYSTEM	OP	5000 FH	1 C	MPD	
273100-00-02	<b>ELEVATOR SYS.</b> FUNCTIONAL CHECK OF ELEVATOR CABLE TENSION REGULATOR	FC	5000 FH	1 C	MPD	
273100-00-09	<b>ELEVATOR SYS.</b> SURV. INSP. OF ELEVATOR HINGE BEARINGS	IN	5000 FH	1 C	MPD	
273500-00-02	<b>STALL WARNING</b> FUNCTIONAL CHECK OF STALL WARNING SYSTEM	FC	5000 FH	1 C	MPD	
274100-00-07	<b>HOR. STABILIZER</b> FUNCTIONAL CHECK OF FRICTION OF HOR. STAB. MECHANICAL CONTROL <b>NOTE:</b> PEDESTAL COVERS TO BE REMOVED.	FC	5000 FH	1 C	MPD	
274200-00-02	<b>HOR. STABILIZER SYS</b> CHECK OIL LEVEL OF STAB. ACTUATOR GEARBOX	SV	5000 FH	1 C	MPD	

<b>Amtoss</b>	<b>Description</b>		<b>Threshold</b>	<b>MPD Int.</b>	<b>PGA Int.</b>	<b>Origin</b>
274300-00-03	<b>HOR. STAB. JAM SW.</b> OP. CHECK OF JAM STAB. SWITCH	OP		5000 FH	1 C	MPD
274400-00-01	<b>HOR STAB. ALTN. CTL.</b> OP CHECK OF STAB ALTERNATE CTRL.	OP		5000 FH	1 C	MPD
274500-00-02	<b>HOR. STAB. POS XDCR.</b> OP. CHECK OF STAB POSITION INDICATION	OP		5000 FH	1 C	MPD
275100-00-01	<b>FLAP MECHANICAL CTL.</b> OIL LEVEL CHECK OF FLAP FEEDBACK ASSY <b>NOTE:</b> LH MLG DOOR TO BE OPENED.	SV		5000 FH	1 C	MPD
275300-00-01	<b>FLAP MECH. ACTUATORS</b> OIL LEVEL CHECK OF MAIN & RIGHT ANGLE GEARBOX <b>NOTE:</b> LEFT AND RIGHT MLG DOORS TO BE OPENED.	SV		5000 FH	1 C	MPD
275300-00-10	<b>FLAP MECH. ACTUATORS</b> OIL LEVEL CHECK OF FLAP ACTUATOR GEARBOXES	SV		5000 FH	1 C	MPD
275400-00-01	<b>ALTERNATE FLAP CONTROL</b> OPERATIONAL CHECK OF FLAP ALTERNATE CONTROL	OP		5000 FH	1 C	MPD
276100-00-02	<b>SPEED BRAKE CONTROL</b> OP. CHECK OF SPEEDBRAKE AUTO-RETRACTION SYSTEM	OP		5000 FH	1 C	MPD
276100-00-03	<b>SPEED BRAKE CONTROL</b> SURVEILLANCE INSP. OF OUTPUT MECHANISM AND SPEED BRAKE ACTUATOR <b>NOTE:</b> SPEED BRAKE OPENED AND SECURED WITH GROUND LOCK.	IN		5000 FH	1 C	MPD
276400-00-04	<b>LIFTDUMPERS HYD. CTL.</b> DRAIN FLUID FROM LIFTDUMPER ACUMULATORS ON GAS SIDE	SV		5000 FH	1 C	MPD
276500-00-01	<b>LIFTD. WARN. AND IND.</b> OP. CHECK OF LIFTDUMPER WARNING	OP		5000 FH	1 C	MPD
277100-00-07	<b>FLIGHT CONTROL LOCK</b> DETAILED INSP. OF ELEVATOR CONTROL LOCK	IN		5000 FH	1 C	MPD
291100-00-02	<b>HYD POWER</b> DRAIN FLUID FROM HYDRAULIC SYSTEM(S) ACUMULATOR GAS SIDE	SV		5000 FH	1 C	MPD

<b>Amtoss</b>	<b>Description</b>	<b>Threshold</b>	<b>MPD Int.</b>	<b>PGA Int.</b>	<b>Origin</b>
291300-00-11	<b>HYDRAULIC POWER</b> IN SURV. INSP. OF HYDRAULIC TUBING, COUPLINGS AND COMPONENTS IN TAIL SECTION (BEHIND REAR BULKHEAD)		5000 FH	1 C	MPD
293100-00-01	<b>HYDRAULIC POWER</b> FC FUNCTIONAL (COMPARISON) CHECK OF RESERVOIR SIGHT GLASS/HYDRAULIC GROUND SERVICING PANEL INDICATOR		5000 FH	1 C	MPD
301100-00-05	<b>WING ANTI-ICING</b> RS RESTORATION OF WING ANTI-ICE MODULATING AND SHUT-OFF VALVE FILTER		5000 FH	1 C	MPD
301200-00-06	<b>TAIL ANTI-ICING</b> RS RESTORATION OF TAIL MODULATING AND SHUTOFF VALVE FILTER		5000 FH	1 C	MPD
302000-00-02	<b>ENGINE AIR INTAKE</b> IN SURVEILLANCE INSPECTION OF DUCTS, INSULATION BLANKETS AND COUPLINGS		5000 FH	1 C	MPD
302000-00-03	<b>ENGINE AIR INTAKE</b> IN SURV. INSP. OF AIR- INTAKE NOSE COWL		5000 FH	1 C	MPD
313100-00-03	<b>FLIGHT DATA RECORDER</b> OP OP. CHECK OF POWER UNIT LOOP		5000 FH	1 C	MPD
315100-00-02	<b>FLIGHT WARNING SYS.</b> OP OP. CHECK OF STANDBY ANNUNCIATOR PANEL (SAP)		5000 FH	1 C	MPD
320001-00-02	<b>LANDING GEAR</b> IN DETAILED INSP. OF LANDING GEAR CONTROL CABLES IN MLG AND NLG WHELL BAYS AND IN THE TUNNEL BETWEEN THE WHEEL BAYS (OUTSIDE PRESSURE CABIN) <b>NOTE:</b> MLG DOORS TO BE OPENED.		5000 FH	1 C	MPD
320001-00-05	<b>LANDING GEAR</b> IN SURV. INSP. OF PULLEYS, FAIRLEEDS, PRESSURE SEALS AND BRACKETS OF LANDING GEAR CONTROL CABLE SYSTEM IN MLG AND NLG WHEEL BAYS AND IN THE TUNNEL BETWEEN THE WHEEL BAYS <b>NOTE:</b> MLG DOORS TO BE OPENED.		5000 FH	1 C	MPD
321100-00-03	<b>MAIN LANDING GEAR</b> IN DETAILED INSP. OF MLG		5000 FH	1 C	MPD
322100-00-03	<b>NOSE LANDING GEAR</b> IN DETAILED INSP. OF NLG		5000 FH	1 C	MPD

<b>Amtoss</b>	<b>Description</b>		<b>Threshold</b>	<b>MPD Int.</b>	<b>PGA Int.</b>	<b>Origin</b>
322201-00-02	<b>NOSE LANDING GEAR</b> DETAILED INSP. OF NLG DOORS OPERATING MECHANISM, INCLUDING HINGES.  <b>NOTE:</b> PAY SPECIAL ATTENTION TO THE AREAS ADJACENT TO THE SHAFT (P/N A82020-403) WELDINGS.	IN		5000 FH	1 C	MPD
323200-00-04	<b>NOSE LANDING GEAR</b> INSP. FOR EXCESSIVE PLAY AT DOWNLOCK PLUNGER MECHANISM	IN		5000 FH	1 C	MPD
323300-00-01	<b>LANDING GEAR</b> LUB. OF MLG AND NLG DOOR UPLOCK MECHANISM  <b>NOTE:</b> MLG DOORS TO BE OPENED.	LU		5000 FH	1 C	MPD
323300-00-04	<b>MAIN LANDING GEAR</b> SURV. INSP. OF DUMP VALVE OPERATING MECHANISM  <b>NOTE:</b> RH MLG DOOR OPEN.	IN		5000 FH	1 C	MPD
324300-00-04	<b>MLG BRAKE MECH. CTL</b> SURV. INSP. OF BRAKE CONTROL VALVE OPERATING MECHANISM OUTSIDE PRESSURE CABIN	IN		5000 FH	1 C	MPD
324400-00-01	<b>MLG BRAKE HYDRAULIC CTL</b> OP. CHECK OF AUTOMATIC CHANGE OVER VALVE	OP		5000 FH	1 C	MPD
324400-00-03	<b>MLG BRAKE HYDRAULIC CTL</b> DRAIN ALTERNATE DRAIN ACCUMULATOR (GAS SIDE)	SV		5000 FH	1 C	MPD
325100-00-05	<b>NLG STEERING</b> FUNCTIONAL CHECK OF NOSE WHEEL STEERING MECHANICAL CONTROL	FC		5000 FH	1 C	MPD
325200-00-01	<b>NLG STEERING MECH.</b> OIL LEVEL CHECK OF STEERING MOTOR	IN		5000 FH	1 C	MPD
325200-00-02	<b>NLG STEERING HYD. CTRL</b> OP. CHECK OF NOSE WHEEL STEERING ON-OFF CIRCUIT	IN		5000 FH	1 C	MPD
344300-01-01	<b>GROUND PROX. WARNING</b> OPERATIONAL CHECK OF ENHANCED GROUND PROXIMITY WARNING SYSTEM (EGPWS).  <b>NOTE:</b> MRB SECTION 01, PARAGRAPH 4.f.	OP		5000 FH	1 C	MPD
360000-00-01	<b>PNEUMATICS</b> INSP. OF LOW PRESSURE CHECK VALVE	IN		5000 FH	1 C	MPD
360000-00-03	<b>PNEUMATICS</b> INSP. OF HIGH PRESSURE CHECK VALVE	IN		5000 FH	1 C	MPD

<b>Amtoss</b>	<b>Description</b>		<b>Threshold</b>	<b>MPD Int.</b>	<b>PGA Int.</b>	<b>Origin</b>
360000-00-07	<b>PNEUMATICS</b> FUNC. CHECK OF PNEUMATIC THERMOSTAT	FC		5000 FH	1 C	MPD
491000-00-01	<b>APU ENGINE DRAINS</b> INSP. OF INLET PLENUM DRAIN LINE, TURBINE PLENUM DRAIN LINE & EXHAUST DRAIN LINE INCLUDING ORIFICE FOR BLOCKAGE	IN		5000 FH	1 C	MPD
495200-00-01	<b>APU VENTILATION SYS.</b> INSP. OF VENT. SHUT-OFF VALVE	IN		5000 FH	1 C	MPD
521102-00-09	<b>PAX DOOR ACT. MECH.</b> FUNCTIONAL CHECK OF PAX DOOR ACTUATING FRICTION MECHANISM	FC		5000 FH	1 C	MPD
521102-00-10	<b>PAX DOOR ACT. MECH.</b> DETAILED INSP OF PAX DOOR BEARINGS IN ACTUATING MECHANISM LEVER & BRACKETS	IN		5000 FH	1 C	MPD
521104-00-01	<b>PAX DOOR REL. MECH.</b> OP. CHECK OF PAX DOOR EMERGENCY RELEASE MECHANISM  <b>NOTE:</b> PAX DOOR TO BE OPENED.	OP		5000 FH	1 C	MPD
522102-00-01	<b>EMER. EXITS LOCKING</b> LUBRICATION OF OVERWING EMERG. EXITS LATCHING & LOCKING MECHANISM  <b>NOTE:</b> REMOVE TRIM PANELS.	LU		5000 FH	1 C	MPD
522102-00-02	<b>EMER. EXITS LOCKING</b> OPERATIONAL CHECK OF OVERWING EMERGENCY EXITS LATCHING AND LOCKING MECHANISM	OP		5000 FH	1 C	MPD
523002-00-01	<b>CARGO DOORS LOCKING</b> FUNCTIONAL CHECK OF CARGO DOORS LATCHING & LOCKING MECHANISM  <b>NOTE:</b> CHECK ALSO INSPECTION WINDOWS OF CARGO DOORS. <b>NOTE:</b> TASK NOT APPLIC.TO CENT CARGO DOOR IF MBL IS INST.	FC		5000 FH	1 C	MPD
523002-00-02	<b>CARGO DOORS LOCKING</b> DETAILED INSPECTION OF CARGO DOORS LOCK LEVER/SLOTTED HOLE IN DOOR HANDLE.  <b>NOTE:</b> TASK NOT APPLIC.TO CENT CARGO DOOR IF MBL IS INST.	IN		5000 FH	1 C	MPD
523002-00-03	<b>CARGO DOORS LOCKING</b> LUBRICATION OF CARGO DOORS VENT FLAP MECHANISM BEARINGS  <b>NOTE:</b> CHECK ALSO VENT FLAP SEALS. <b>NOTE:</b> TASK NOT APPLIC.TO CENT CARGO DOOR IF MBL IS INST.	LU		5000 FH	1 C	MPD

<b>Amtoss</b>	<b>Description</b>	<b>Threshold</b>	<b>MPD Int.</b>	<b>PGA Int.</b>	<b>Origin</b>
524102-00-02	<b>FWD S/E DOOR LOCKING</b> LU LUBRICATION OF FWD S/E DOOR HINGE DRIVE SHAFT BUSHINGS & SPHERICAL BEARINGS, OUTBOARD HANDLE MECHANISM & C-LATCH BUSHINGS.  <b>NOTE:</b> FWD. S/E DOOR TO BE OPENED. <b>NOTE:</b> REMOVE DOOR HANDLE COVER.		5000 FH	1 C	MPD
524102-00-06	<b>FWD S/E DOOR</b> OP OPERATIONAL CHECK OF FWD S/E DOOR PARKING HOOK MECHANISM.  <b>NOTE:</b> FWD. S/E DOOR TO BE OPENED.		5000 FH	1 C	MPD
524154-00-01	<b>FWD S/E DOOR, EXT.</b> IN SURVEILLANCE INSP. OF THE EXTERNAL PARTS OF HINGE SPILOTS & RECESSES OF FWD S/E DOOR		5000 FH	1 C	MPD
524155-00-01	<b>FWD S/E DOOR, EXT.</b> IN SURVEILLANCE INSP. OF EXTERNAL PART OF FWD S/E DOOR UPPER SPIGOT		5000 FH	1 C	MPD
524301-00-01	<b>AVIONICS BAY HATCH</b> IN SURVEILLANCE INSP. OF AVIONICS BAY HATCH(ES) SEALS		5000 FH	1 C	MPD
524302-00-01	<b>AVIONICS BAY HATCH</b> LU LUBRICATION OF CONTACT SURFACES OF LATCHING PIN AND GUIDE FITTING OF THE AVIONICS BAY HATCH(ES)		5000 FH	1 C	MPD
524302-00-03	<b>AVIONICS BAY HATCH</b> IN SURVEILLANCE INSP. OF AVIONICS BAY HATCH(ES) LATCHING PINS/LATCH BRACKETS		5000 FH	1 C	MPD
524502-00-02	<b>REAR S/E DOOR LOCK.</b> LU LUBRICATION OF REAR S/E DOOR HINGE DRIVE SHAFT BUSHINGS, SPHERICAL BEARINGS, OUTBOARD HANDLE MECHANISM & C-LATCH BUSHINGS  <b>NOTE:</b> REAR S/E DOOR TO BE OPENED <b>NOTE:</b> REMOVE DOOR HANDLE COVER.		5000 FH	1 C	MPD
524502-00-06	<b>REAR S/E DOOR</b> OP OPERATIONAL CHECK OF REAR S/E DOOR PARKING HOOK MECHANISM  <b>NOTE:</b> REAR S/E DOOR TO BE OPENED		5000 FH	1 C	MPD
524554-00-01	<b>REAR S/E DOOR, EXT.</b> IN SURVEILLANCE INSP. OF EXTERNAL PARTS OF HINGE SPIGOTS & RECESSES OF THE REAR S/E REAR DOOR		5000 FH	1 C	MPD
524555-00-01	<b>REAR S/E DOOR, EXT.</b> IN SURVEILLANCE INSP. OF EXTERNAL PART OF REAR S/E DOOR UPPER SPIGOT		5000 FH	1 C	MPD

<b>Amtoss</b>	<b>Description</b>		<b>Threshold</b>	<b>MPD Int.</b>	<b>PGA Int.</b>	<b>Origin</b>
527100-00-01	<b>DOOR LOCK WARNING</b> OPERATIONAL CHECK OF DOOR LOCK WARNING SYSTEM	OP		5000 FH	1 C	MPD
531404-00-01	<b>FUSELAGE</b> SURV. INSP. OF SEALS OF ACCESS HATCHES FOR FLIGHT CONTROLS AND EQUIPMENT COOLING COMPARTMENTS	IN		5000 FH	1 C	MPD
531405-00-01	<b>FUSELAGE</b> LUBRICATION OF HANDLE SHAFT BEARINGS AND CONTACT SURFACES LATCHING PIN/GUIDE FITTINGS OF FLIGHT CONTROLS & EQUIPMENT COOLING COMPARTMET ACCESS HATCHES	LU		5000 FH	1 C	MPD
531405-00-04	<b>FUSELAGE</b> SURV. INSP. OF LATCHING PIN/LATCH BRACKETS OF FLIGHT CONTROLS & EQUIPMENTS COOLING COMPARTMENTS ACCESS HATCHES	IN		5000 FH	1 C	MPD
533025-00-01	<b>CENTER FUSELAGE, INT</b> SURV. INSP. OF FRONT SIDE OF PRESSURE BULKHEAD AT STA 18451	IN		5000 FH	1 C	MPD
534301-00-02	<b>SPEED BRAKES</b> SURV. INSP. OF THE EXTERNAL SIDE OF THE OUTBOARD SKIN PANELS OF THE SPEEDBRAKES	IN		5000 FH	1 C	MPD
554002-00-03	<b>RUDDER</b> LUBRICATION OF RUDDER UPPER HINGE LINK PIVOT	LU		5000 FH	1 C	MPD
562000-00-01	<b>PAX COMPT. WINDOWS</b> SURV. INSP. OF PASSENGER COMPARTMENT WINDOWS (INCL. OBSERVATION WINDOWS) <b>NOTE:</b> CHECK ALSO WINDOW SHADES.	IN		5000 FH	1 C	MPD
572018-01-01	<b>OUTER WING, EXT</b> SURV. INSP. OF OUTER WING LOWER SKIN EXTERNAL IN AREAS COVERED BY WING TO FUSELAGE FAIRING, INCLUDING: - SKIN BETWEEN AUX. FRONT SPAR AND REAR SPAR; SKIN BETWEEN REAR SPAR AND FALSE SPAR; ACESS PANELS AND BUTTSTRAPS.	IN		5000 FH	1 C	MPD
572032-00-01	<b>OUTER WING, INT</b> SURV. INSP. OF MLG BRACKET, SIDE STAY BRACKET SUPPORT BEAM <b>NOTE:</b> APPLY CIC.	IN		5000 FH	1 C	MPD
712103-00-02	<b>ENG. VIB. ISOLATORS</b> INSP. OF TOP ISOLATORS	IN		5000 FH	1 C	MPD

<i>Amtoss</i>	<i>Description</i>		<i>Threshold</i>	<i>MPD Int.</i>	<i>PGA Int.</i>	<i>Origin</i>
761100-00-10	<b>THRUST CONTROL</b> FUNCTIONAL CHECK OF THRUST REVERSER OPERATING MECHANISM AND THE THRUST REVERSER SWITCH ON THE THRUST LEVER SWITCHBOX.	FC		5000 FH	1 C	MPD

---

<i>Amtoss</i>	<i>Description</i>	<i>Threshold</i>	<i>MPD Int.</i>	<i>PGA Int.</i>	<i>Origin</i>
	Quantity of tasks in this category	128			

---

<b>Amtoss</b>	<b>Description</b>		<b>Threshold</b>	<b>MPD Int.</b>	<b>PGA Int.</b>	<b>Origin</b>
062305-00-02	<b>APU COMPARTMENT</b> SURV. INSPECTION OF AREA BELOW APU ENCLOSURE, INTERNALLY <b>NOTE:</b> REMOVE 3 MAINTENANCE PANELS TO GAIN ACCESS BELOW APU ENCLOSURE	IN		6000 FH	1 C	MPD
213000-00-02	<b>AIR CONDITIONING</b> CLEAN AIR JET PUMP OUTFLOW OPENINGS <b>NOTE:</b> OPTIONAL MAINTENANCE TASK: 213100-50-01	SV		12000 FH	1 C	MPD
213000-00-03	<b>AIR CONDITIONING</b> DISCARD CABIN AIR FILTER <b>NOTE:</b> CARGO COMPARTMENT LINING TO BE REM. AS FAR AS REQ. <b>NOTE:</b> CENTER CARGO DOOR TO BE OPENED.	DS		8000 FH	1 C	MPD
236000-00-01	<b>STATIC DISCHARGING</b> FUNCTIONAL CHECK OF STATIC DISCHARGERS.	FC		6000 FH	1 C	MPD
237100-00-04	<b>VOICE RECORDING</b> RESTORATION OF THE COCKPIT VOICE RECORDER	RS		VEN REC	1 C	MPD
262100-00-05	<b>ENG. FIRE EXTING.</b> OP. CHECK OF ENGINE FIRE HANDLES	OP		6000 FH	1 C	MPD
274100-01-06	<b>HOR. STABILIZER SYS</b> FUNCTIONAL CHECK OF HOR. STAB. PIVOT BEARINGS	FC		6000 FH	1 C	MPD
275300-00-06	<b>FLAP MECHANICAL DRIVE</b> FUNCTIONAL CHECK OF FLAP ACTUATOR NUTS BACKLASH <b>NOTE:</b> RESTORE IMMEDIATELY IF THE REINSPECTION IS DUE BEFORE 1000 FH	FC		6000 FH	1 C	MPD
280000-00-03 ALI	<b>FUEL</b> DETAILED INSPECTION OF THE DRAIN HOLES IN THE DRY BAY ZONES <b>NOTE:</b> SFAR 88	IN	01/01/2009	6000 FH	1 C	MPD
284300-00-01	<b>FUEL LOW PRESS.WARN</b> OP.CHECK OF BOOSTER PUMP PRESSURE SWITCHES	OP		8000 FH	1 C	MPD
293700-00-01	<b>HYDRAULIC POWER</b> FUNCTIONAL CHECK OF HYDRAULIC SYSTEM 1 AND 2 FILTER DIFFERENTIAL PRESSURE INDICATION SYSTEM	FC		12000 FH	1 C	MPD
321100-00-08	<b>MAIN LANDING GEAR</b> INSP. FOR PLAY AT TORQUE LINK UPPER AND LOWER HINGE POINTS	IN		5000 FC	1 C	MPD
321100-00-10	<b>MAIN LANDING GEAR</b> DETAILED INSP. OF WATER SPRAY DEFLECTOR	IN		4000 FC	1 C	MPD
322100-00-08	<b>NOSE LANDING GEAR</b> INSP. OF TORQUE LINK UPPER AND LOWER HINGE POINTS	IN		4000 FC	1 C	MPD

<b>Amtoss</b>	<b>Description</b>		<b>Threshold</b>	<b>MPD Int.</b>	<b>PGA Int.</b>	<b>Origin</b>
323100-00-01	<b>LANDING GEAR</b> LUB. OF TELEFLEX CABLE	LU		6000 FH	1 C	MPD
323300-00-05	<b>LANDING GEAR</b> SURV. INSP. OF LANDING GEAR DOOR UPLOCK RELEASE OPERATING MECHANISM	IN		6000 FH	1 C	MPD
324400-00-02	<b>MLG BRAKE HYDRAULIC CTL</b> FUNCTIONAL CHECK OF ALTERNATE BRAKE CONTROL SYSTEM	FC		8000 FH	1 C	MPD
352100-00-01	<b>PASSENGER OXYGEN</b> FUNCTIONAL CHECK OF PASSENGER OXYGEN DROP- OUT SYSTEM	FC		4 YR	1 C	MPD
360000-00-02	<b>PNEUMATICS</b> INSP. OF GROUND SUPPLY CHECK VALVE	IN		8000 FH	1 C	MPD
381200-00-01	<b>CENTRAL WATER SYSTEM</b> STERILIZATION OF CENTRAL WATER SYSTEM	SV		NT	1 C	MPD
521153-00-01	<b>PASSENGER DOOR, EXT.</b> SURV. INSP. OF PAX DOOR HINGE HALVES	IN		6 YR	1 C	MPD
531001-00-02 ALI	<b>FWD. FUSELAGE, EXT.</b> SPECIAL DETAILED INSP. OF FUSELAGE FRAME STRIPS AT STA 3820-3870 AT THE AFT SIDE OF NLG- BAY	IN	20000 FC	3500 FC	1 C	MPD
531016-00-02	<b>FWD. FUSELAGE, INT.</b> SPECIAL DETAILED INSP. OF THE FWD PRESSURE BULKHEAD AT THE WEB PLATES AND RADII OF THE HORIZONTAL BEAMS (WEB SIDE) <b>NOTE:</b> ANTENNA BASE PLATE TO BE REMOVED. <b>NOTE:</b> MRB SECTION 03, PARAGRAPH 2.e. <b>NOTE:</b> SOUND PROOFING TO BE REMOVED AS FAR AS REQ.	IN	17000 FC	4200 FC	1 C	MPD
531023-00-01	<b>FWD. FUSELAGE, INT.</b> SURVEILLANCE INSP. OF FRONT SIDE OF NLG BRACKET AT STA 3820 <b>NOTE:</b> APPLY CIC.	IN		8000 FH	1 C	MPD
531451-00-01	<b>ACCESS PANELS, INT</b> SURVEILLANCE INSPECTION OF SKIN AND PAN EXTERNAL OF ACCESS HATCH OF THE FLIGHT CONTROLS AND ACCESS HATCHES OF THE EQUIPMENT COOLING COMPARTMENTS <b>NOTE:</b> INTERVAL 6000 FH OR 3 YR WHICHEVER COMES FIRST. <b>NOTE:</b> NEW TASK (REV. OUT/01).	IN	3 YR	3 YR	1 C	MPD
544000-00-01	<b>STUBWING, INT.</b> LUBRICATION OF FWD SIDE VIBRATION ISOLATOR TO ENGINE FITTING ATTACHMENT; FWD ENGINE MOUNT LINK ASSEMBLY; AFT ENGINE MOUNT LINK ASSEMBLY;ENGINE SUPPORT FITTINGS	LU		2 YR	1 C	MPD

<b>Amtoss</b>	<b>Description</b>		<b>Threshold</b>	<b>MPD Int.</b>	<b>PGA Int.</b>	<b>Origin</b>
572015-00-03	<b>OUTER WING, EXT</b> SURVEILLANCE INSPECTION OF FASTENERS THROUGH MLG BRACKET AND UPPER SKIN PANEL <b>NOTE:</b> MLG DOORS TO BE OPENED.	IN	25000 FC	5000 FC	1 C	MPD
572018-00-09	<b>OUTER WING, EXT</b> SURVEILLANCE INSPECTION OF FASTENERS THROUGH MLG BRACKET AND LOWER SKIN PANEL	IN	25000 FC	5000 FC	1 C	MPD
575502-00-01	<b>INNER FLAP VANE, EXT.</b> DETAILED INSP. OF INNER FLAP VANE SWIVEL JOINTS AT WS 2388 AND WS 4426 EXTERNAL, INCLUDING CONNECTION TO VANE TRACK <b>NOTE:</b> FLAPS TO BE FULLY EXTENDED.	IN		3 YR	1 C	MPD
575602-00-01	<b>OUTER FLAP VANE, EXT.</b> DETAILED INSP. OF OUTER FLAP VANE SWIVEL JOINT BAT WS 5965 AND WS 7559 EXTERNAL, INCLUDING CONNECTION TO VANE TRACK <b>NOTE:</b> FLAPS TO BE FULLY EXTENDED.	IN		3 YR	1 C	MPD
730000-00-05	<b>ENGINE FUEL SYS.</b> OPERATIONAL CHECK OF APPROACH IDLE SYSTEM	OP		8000 FH	1 C	MPD
773100-00-02	<b>ENG. FAILURE SENSING</b> OPERATIONAL CHECK OF ENGINE FAILURE SENSING SYSTEM	OP		6000 FH	1 C	MPD
774100-00-01	<b>ENGINE INDICATING</b> OPERATIONAL CHECK OF ENGINE OUT SYSTEM	OP		6000 FH	1 C	MPD

---

<i>Amtoss</i>	<i>Description</i>	<i>Threshold</i>	<i>MPD Int.</i>	<i>PGA Int.</i>	<i>Origin</i>
---------------	--------------------	------------------	-----------------	-----------------	---------------

---

	Quantity of tasks in this category	33			
--	------------------------------------	----	--	--	--

<b>Amtoss</b>	<b>Description</b>		<b>Interval MPD</b>	<b>Interval PGA</b>	<b>Origin</b>
212900-00-50	<b>AIR CONDITIONING</b> INSPECT AIR CONDITIONING GROUND CONNECTION	IN		1 C	MRI
<b>Ref</b>	AMM 21-29-00				
221100-00-50	<b>AUTO FLIGHT</b> PROTECTION AND TESTING OF THE ELEVATOR, RUDDER ANDAILERON SERVO MOTOR CONNECTORS IAW SBF100-22-040	SV		1 C	PGA
<b>Ref</b>	SBF100-22-040				
251400-00-50	<b>EQUIPMENT/FURNISHING</b> FLIGHT COMPARTMENT LINING CHECK FOR STRAINS, DAMAGE, WEAR & PROPER ATTACHMENT	IN		1 C	MRI
<b>Ref</b>	AMM 25-14-00				
251500-00-50	<b>EQUIPMENT/FURNISHING</b> FLOOR COVERING FLIGHT COMP. CHECK FOR STRAINS, LOOSE PARTS, WEAR & DAMAGE	IN		1 C	MRI
<b>Ref</b>	AMM 25-15-00				
252300-00-51	<b>EQUIPMENT/FURNISHING</b> SIDEWALL PANELS CHECK FOR STRAIN, DAMAGE, WEAR & POWER ATTACHMENT	IN		1 C	MRI
<b>Ref</b>	AMM 25-23-00				
252400-00-50	<b>EQUIPMENT/FURNISHING</b> CEILING PANELS CHECK FOR STRAINS, WEAR & PROPER ATTACHMENT	IN		1 C	MRI
<b>Ref</b>	AMM 25-24-00				
252601-00-50	<b>EQUIPMENT/FURNISHING</b> PARTITIONS & CURTAINS CHECK FOR STRAINS, DAMAGE,WEAR & PROPER ATTACHMENT	IN		1 C	MRI
<b>Ref</b>	AMM 25-26-00				
252701-00-51	<b>EQUIPMENT/FURNISHING</b> CHECK OVERHEAD STOWAGE BINS FOR PROPER OPERATION, ALIGNMENT, LATCHING AND GENERAL CONDITION	IN		1 C	MRI
<b>Ref</b>	AMM 25-27-00				
254000-00-50	<b>LAVATORY</b> LAVATORY EQUIPMENT: CHECK CONDITION OF CABINET HOLDERS AND DISPENSERS WITH HINGES AND LOCKS WASH STAND: TOILET AND SEAT COVER.	IN		1 C	MRI
<b>Ref</b>					
254000-00-51	<b>LAVATORY</b> LAVATORY CEILINGS CHECK CONDITION & CLEANLINES OF COVERING MATERIAL ON CEILING/SIDEWALLS FLOOR	IN		1 C	MRI
<b>Ref</b>					
270001-00-50	<b>FLIGHT CTL. CABLES</b> AILERON WING & ANTI-UPFLOAT CABLES	LU		1 C	MRI
<b>Ref</b>	AMM 12-21-05/301 FF AMM 12-21-06 FF				

<b>Amtoss</b>	<b>Description</b>		<b>Interval MPD</b>	<b>Interval PGA</b>	<b>Origin</b>
284300-00-50	<b>FUEL</b> ATTITUDE MONITOR CHECK FOR GENERAL CONDITION	IN		1 C	MRI
<b>Ref</b>	AMM 28-42-00				
320001-00-50	<b>LANDING GEAR</b> NOSE WHEEL STEERING CABLES AT PRESSURE SEAL	LU		1 C	MRI
<b>Ref</b>	AMM 12-36-01/301 FF				
320001-00-51	<b>LANDING GEAR</b> LDG GEAR ALTERNATE DOWN CABLE AT PRESSURE SEALS	LU		1 C	MRI
<b>Ref</b>	AMM 12-36-01/301 FF				
324400-00-07	<b>LANDING GEAR</b> BRAKE MECHANICAL CONTROL RIGGING	IN		1 C	PGA
<b>Ref</b>	AMM 32-44-00-720-815-A				
342400-00-50	<b>NAVIGATION</b> COMPASS SWING	FC		1 C	MRI
<b>Ref</b>	AMM 34-24-00-720-815-A				
345300-00-50	<b>NAVIGATION</b> EXTERNAL INSPECTION OF ADF ANTENNA SURFACE SEALANT CONDITION	IN		1 C	MRI
<b>Ref</b>	AMM 34-53-03				
361114-00-50	<b>SHUTTLE VALVE</b> SURV. INSP. OF THE SHUTTLE VALVE	IN		1 C	PGA
<b>Ref</b>	AMM 36-11; SED 36-11/001 <b>NOTE:</b> D74326-401 (INTRODUCED WITH SBF100-36- 008) <b>NOTE:</b> TASK TO GIVE CONTINUITY TO EO2506				
383100-00-51	<b>LAVATORY</b> REMOVE THE SINK DRAIN VALVES AND CHECK FOR PROPER OPERATION. (NO CABIN PRESSURE LEAKS)	IN		1 C	MRI
<b>Ref</b>	AMM 38-31-00-ZZ3-810-A				
383100-00-53	<b>LAVATORY</b> CHECK FOR LEAKS ON LAVATORY PIPING	IN		1 C	MRI
<b>Ref</b>	AMM 38-31-00				
383100-00-54	<b>WATER/WASTE</b> LAVATORY WASTE DRAIN CONNECTION. REPLACE SEAL OF CAP ASSY	IN		1 C	MRI
<b>Ref</b>	AMM 38-31-05 TBD				
383100-00-57	<b>LAVATORIES</b> CLEANING OF WASTE TANK VENTILATION PIPING	RS		1 C	PGA
<b>Ref</b>	SED 38-31				
511100-00-50	<b>STANDARD PRACTICES AND STRUCTURES</b> EXTERNAL VISUAL INSPECTION OF FUSELAGE DRAIN SYSTEM	IN		1 C	MRI
<b>Ref</b>	AMM 52-12-00/201 FF				

<b>Amtoss</b>	<b>Description</b>	<b>Interval MPD</b>	<b>Interval PGA</b>	<b>Origin</b>
520000-00-50	<b>DOORS</b> SERVICE ACCESS PANELS: CHECK SERV. ACCESS PANELS EQUIPED WITH QUICK RELEASE LATCHES  <b>Ref</b> SIM 52-8000	IN	1 C	MRI
524402-00-50	<b>DOORS</b> CHECK CONDITION OF APU COMPARTMENT DOOR SEAL  <b>Ref</b> AMM 52-44-01	IN	1 C	MRI
537318-00-50	<b>TAIL SECTION, INT.</b> SURV. INSPECTION OF THE UPPER CONNECTION ANGLES OF THE OBLIQUE FRAMES  <b>Ref</b> SBF100-53-086 <b>NOTE:</b> CRACKS USUALLY OCCUR IN THE RADIUS OF THE CONNECTION ANGLE FLANGES WHICH ARE ATTACHED TO THE L-SHAPED PROFILE WHICH CONNECTS THE VERT. STAB. SKIN TO THE TAIL SECTION SKIN.	IN	1 C	PGA
541010-00-50	<b>ACOUSTIC PANELS</b> INSPECTION OF ACOUSTIC PANELS FOR MESH DELAMINATION  <b>Ref</b> SRM 54-10-01/02	IN	1 C	PGA
543200-00-50	<b>ACCESS PANELS, INT</b> SURV INSP. OF ALL ACCESS PANELS LOCATED IN THE POWERPLANT AND STRUT LH/RH. CHECK HINGES, (QUICK RELEASE) LATCHES AND WEAR PLATES (A/C STRUCTURE)  <b>Ref</b> <b>NOTE:</b> POWERPLANT AND STRUT (LH/RH)	IN	1 C	PGA
564100-00-50	<b>WINDOWS-INSPECTION WINDOWS</b> SURVEILLANCE INSPECTION OF CARGO DOOR (FWD, MID AND AFT) INSPECTION WINDOWS  <b>Ref</b> AMM 56-41-00-200-816	IN	1 C	MRI

---

<i>Amtoss</i>	<i>Description</i>	<i>Interval MPD</i>	<i>Interval PGA</i>	<i>Origin</i>
	Quantity of tasks in this category			29

---